

DAISY COMPACT M ERRORS AND THEIR DEFINITIONS

№	Display text	Definition	Comment
1	OVERFLOW	Full Memory. Change Memory Card.	Contact the technician
7	OPER.FORBIDDEN	Fix the error with the following key combination: press the C and then the TL keys.	
14	WRONG SYMBOL/WRONG KEY	A wrong combination of keys is pressed. Turn off/on the cash register to restart it.	
66	ERROR 66	Invalid password	Submit valid password
71	* SUBSTITUTION FM	Memory Damage	Contact the technician
81	OFL.DAILY REP.	The daily financial report is full	Click the C button and take the daily financial report by restarting
82	OVERFLOW 24h	Print the Z report	Click the C button and take the daily Z report
107	** SIM CARD LOCKED	Damaged SIM, needs to be changed	Contact the technician

Notes

* It refers to computer mode only. Error is sent to the program and does not appear on the fiscal device.

** You can not continue working. Please contact your service provider immediately.